

## BaktEx® Mould remover

### CLP-label-free Mould remover

- ✓ Chlorine bleach free
- ✓ VOC free
- ✓ Hydrogen peroxide free
- ✓ QAV free
- ✓ Nanomaterial free
- ✓ Odourless

### Product Description

- No special protective equipment is required
- Cost-efficient and economically effective use with an effect that is achieved in 60 minutes after applying the mould remover
- Chlorine-free, therefore no chlorine gas is formed
- All raw materials used in **BaktEx® mold remover** are vegan, halal as well as kosher

### Application / Spectrum of action / Exposure times / Dosage:

Spray product (90ml/m<sup>2</sup>) onto the affected area, leave on for 60 minutes. Then clean with clean water. Due to the chlorine-free mode of action, mould and mildew stains are not bleached and must then be removed with a damp sponge.

### Chemical-physical properties:

Appearance: clear liquid  
Density (20 °C): ca. 1,000 g/cm<sup>3</sup>  
pH-value: (20 °C): ca. 3,6

## Hints

- Check product durability and material compatibility in an inconspicuous area
- Keep the product out of the reach of children
- Do not spray plants
- Avoid eye contact
- Clean tools with water after use

## Product quality

- The production and labelling is carried out in accordance with the valid EU directives and the GHS

## Environment

- The packaging material is made of polyethylene and after complete emptying, can be disposed of as plastic waste via the dual system for proper recycling
- Water hazard class 1 (self-classification)

## Storage instructions

**BaktEx® Mould remover** is regulated according to GHS and can be stored in closed containers. Store at 10 - 28°C for at least 18 months. Also it is VOC free. Store the container in a well ventilated place. Keep the container tightly closed. Protect from frost and direct sunlight

## Legal requirements

- Safety data sheet available on request

✓ Chlorine bleach free ✓ VOC frei

✓ Hydrogen peroxide free ✓ QAV frei ✓ Nanomaterial frei

✓ Odourless

## Contact:

If you have any questions, the advisory service of Azett GmbH & Co. KG, led by Dr. Thomas Meneghini, is happy to assist you.

T.: +49 (0)8393 92270-0

E.: [info@azett.de](mailto:info@azett.de)